

AF QUADRANT FITTING INSTRUCTIONS

- Ensure shower tray is level and check that adjustment sizes given are correct fitment to your application. Care must be taken when drilling into walls to avoid hidden pipes or electrical cables (Fig1).
- Assemble the frame by fixing the top and bottom rails to the fixed glass panel by first sliding the glass clips into the groove in the top and bottom rails with the open end facing outward (Fig 2), then slide the glass seal into the groove until it is fully home and retained under the glass clip (Fig 3). Place the end caps on either ends of the rails making sure to snap out the top bar (see sketch "B") (Fig4). Then push the glass fixed panel into the seals in the top and bottom rails (Fig 5) and fix through the aluminium post into the rails using the 40 mm screws (Fig 6).
- Fit rubber door stops using 10 mm roundhead screws (Fig 7).
- Take wall posts and set 15 mm in from edge of tray, using a spirit level ensure wall posts are vertical and plumb (fig 8) mark hole positions (fig9), remove and drill holes and fit wall plugs.
- Slide wall posts onto either side of the frame, carefully lift frame into position and fix to wall using 30 mm screws ensure screw collar are fitted to the screw beforehand. Taking care not to scratch the unit mark and drill two 3.2 mm holes 150 mm from top and bottom on the inside of the enclosure through the wall posts and frame (fig 10) and secure with 10 mm screw again ensure the screw collar is in place.
- Fix top wheels to the glass doors by unclipping and lowering the cover cap, undo the retaining nut and fix through the holes in the glass re-tighten (fig 11) (final adjustment can be made by slackening the nut when assembly of unit is complete).
- Fix bottom wheels into position by disassembling wheel assembly and placing plastic saddle over the glass and tighten in position through the hole in the glass, place spring over spigot within wheel housing (see sketch A) and slide wheel onto the plastic saddle and re-fit cover cap (Fig 12).
- Hang door onto top rail making sure that the wheels are in the channel (fig 13), then from the outside push down on the spring loaded wheels and clip into position (fig 14). Finish by fitting handles supplied.
- Measure and trim to length the magnetic seals and clip onto outside edge of the glass doors (Fig 15).
- Measure and trim to length the vertical water seals and clip into position onto the glass doors and glass side panels (Fig 15).
- Finish off by fitting door handles, screw cover caps and running a bead of silicone along the outside between bottom rail and shower tray and frame work (Fig 16). **(DO NOT SEAL ON THE INSIDE OF THE ENCLOSURE).**

If the door does not run true, final adjustment can be made adjusting the top wheels by slackening the retaining nut and sliding the wheels up or down accordingly.

Figure 1



Figure 2



Figure 3



Figure 4



Figure 5



Figure 6



Figure 7




Figure 8



Figure 9




Figure 10



Figure 11



Figure 12



Figure 13



Figure 14





















Figure 15



Figure 16



AF QUADRANT FITTING INSTRUCTIONS

AF QUADRANT PARTS LIST	
	DOOR STOPS X 8
	10 mm SCREWS FOR DOOR STOPS X 8
	GLASS CLIPS X 4
	GLASS SEAL X 4
	WALL CHANNEL COVERS X 2
	10 mm SCREWS FOR X 4
	30 mm SCREWS X 6
	WALL PLUGS X 6
	40 mm SCREWS X 8
	WALL CHANNEL COVERS X 2
	SCREW COVER CAPS X 10
	INNER SCREW COLLARS X 10
	MAGNETIC SEAL X 2
	DOOR HANDLE ASSEMBLY X 2
	TOP WHEEL ASSEMBLY X 4
	BOTTOM WHEEL ASSEMBLY X 4
	VERTICAL WATER SEAL X 4
	R.H TOP AND BOTTOM RAIL END CAPS X 2
	L.H TOP AND BOTTOM RAIL END CAPS X 2

